V SEVEN

V7 UPS ESXi version 5.x and 6.x Automatic Shutdown 2018-08-01

Note: No additional shutdown wizard software is necessary to install on ESXi 5.x and 6.x. You only need to enable SSH and EXSi shell function on the server.

<u>Directions</u>

1. Enable SSH and EXSi shell function in the ESXi environment. Please follow the instructions from VMWARE
   https://kb.vmware.com/s/article/2004746

2. From the computer with the ViewPower Pro software, make sure you log in as administrator. On the Load Configuration screen click **Add**, then enter the IP Address of the server you want to automatically shutdown, check **Enable SSH shutdown**, enter the correct **User name** and Password of the ESXi server (default user is root), then select the UPS device and other settings as desired and click **Apply**.